

801-280-2281

[info@flagspolesbanners.com](mailto:info@flagspolesbanners.com)



## Bob A Loon

### "Reusable Balloon" Assembly Instructions

1) Remove from plastic bag.



2) Gently slide "balloon clip" all the way into one side of balloon clip pocket.



3) Pull flap with retainer hole over the center post and place the edge of the flap between the post and clip (not over both clips).



4) Slide the clip into the remaining side. Pull the flap over, and place the hole over the center post, and set in place as step #3.

**(Do not pull retainer hole on one flap over both clips).**



5) Align "balloon clip" snaps with rectangular holes on each side of balloon cup. Snap both sides in place.



6) The round hole on the side of balloon cup should align with balloon air inflation valve on the outside of the balloon.



7) Pinch valve to open check valve flap. This will help increase airflow, and fill the balloon faster.



8) Inflate "reusable balloon".



9) **Warning!! Do not over-inflate!!!**  
The balloons will expand in the heat of the day.



10) Close inflation valve cover.

